

Econo Retractable 33" Banner Stand

SKU: BADISER33

Graphic Installation Instructions



1 Remove end caps from both sides of snap profile




2 Open snap profile



3 Insert graphic into profile, and snap closed



4 Replace end caps on both sides of snap profile



5 Remove adhesive liner



6 Set graphic onto adhesive and set firmly



7 Holding graphic, remove spring key



8 Slowly retract graphic into base