- Six Signs per Frame Messaging
 two 24" x 36" signs

 - two side signs
 - two sided top rider
- Wheels for easy movement
- Quick-Change[™] Feature
 - change signs in seconds, slide in a sign
- Arched top design
 - invisible hinges
- Customizable nameplate
- "Stay Tabs" hold main signs securely in place
- Internally weight with dry sand
- Available in white and black



Patented slot design – just slide in a sign



OUTSIDE DIMENSIONS: 45.54"H X 26.72"W x 3.58"D **DIMENSIONS OF RECESSED AREA:** 34.75"H x 24.25"W

WEIGHT: 24 lbs.

COLORS: White, Black, Custom Colors Available

6 SIGNS PER FRAME

Sand Ballasting Instructions



Each sign frame has two fill holes.

Remove plugs from fill holes and fill each hole with sand. After filling, shake the frame to evenly distribute the sand at the bottom. 5 lbs. of sand per hole for a total of 10 lbs. per sign frame is recommended.


Play sand is suggested for ease of filling.

Main Signs Insertion Instructions:



the tabs





2. ...until sign rests on ground




3. Push sign up into slot



4. Slide sign down into bottom slot

Main Signs

Holds Signs 24"W x 36"H (up to 3/16" thick)



Top Rider Insertion Instructions:

Insert Top Rider Before Inserting Side Signs

Stand the frame on the ground, spreading open the sign faces only half way. Place the Sign Rider in the opening at the top between the sign faces. Now, move the sign faces apart until fully extended.

You may want to cut a hole in the rider to make the handle accessible.



MADE IN THE USA **US PATENTS** 7,337,569 & 7,748,151

PLASTICADE


7707 Austin Avenue Skokie, IL 60077 phone (800) 772-0355 fax (847) 966-8074 Plasticade.com



Side Signs Insertion Instructions:

A cutting template is available at plasticade.com. Holds signs up to 1/4" thick.

If using corrugated plastic sheet for side signs, cut so flutes run horizontal to ground. 4 mm corrugated plastic sheet is recommended.



1. Lay frame flat on the ground. Lift up the top sign face.

Holes



Slide first Side Sign into top and bottom channels on one side of frame.



3. Slide second Side Sign into top and bottom channels on other side of frame.





Watch the Instructional Video on olasticade.com

